


lovehncare™



elite Glider Chair

Instruction Manual BP 883

loveⁿcare™

Congratulations on your new quality Love N Care product from our exclusive range of baby products. This exceptional design combines the most unique features that any baby product offers.

We are confident that you will appreciate its many highlights, including its reliability and durability. Your new product has been manufactured to comply with the Highest Quality Standards and comes with a 12-month warranty.

As you will soon learn there are many more great features about your new Love N Care product.





Safety guidelines and instructions must always be followed before making use of this product, please retain these instructions for future reference.



WARNING: TO AVOID INJURY OR DEATH:

FOLLOW THE MANUFACTURER'S INSTRUCTIONS.

THE MAXIMUM WEIGHT FOR THE SEAT UNIT IS 105KG

It is unsafe to use accessories other than those supplied or approved by Love N Care.

Care should be taken whilst folding and unfolding the glider.

Ensure your child's fingers, hands and all other body parts are clear from any moving part when adjusting the seat or handle on your Glider.

Discontinue using the glider if damaged.

Missing parts should be replaced immediately.

Images are used for illustrative purposes only, the actual item might be different to the item portrayed

CLEANING AND MAINTENANCE

LOVE N CARE PRODUCTS HAVE ONE YEAR WARRANTY FROM THE DATE OF PURCHASE.

IT IS RECOMMENDED TO REGULARLY INSPECT AND MAINTAIN MOVEMENT OF LOCKING DEVICES AND SECURITY OF ESSENTIAL COMPONENTS.

REGULARLY CHECK ALL PARTS FOR WEAR AND TEAR.

DO NOT USE SPRAY LUBRICANTS, SIMPLY WIPE CLEAN AFTER USE.

THE SEAT LINER CAN BE CLEANED BY SPONGING WITH WARM SOAPY WATER AND A MILD DETERGENT. A MILD DISINFECTANT MAY BE USED IF DESIRED.

STUBBORN MARKS MAY BE REMOVED WITH A NON ABRASIVE CREAM CLEANER.

NEVER CLEAN WITH ABRASIVE, AMMONIA BASED, BLEACH BASED OR SPIRIT TYPE CLEANERS.

ABRIC CARE

- HAND WASH ONLY
- DO NOT BLEACH
- DO NOT TUMBLE DRY
- DO NOT IRON
- DO NOT WRING
- DO NOT DRY CLEAN



PARTS LIST

1.



2.







3.



4.



WHEN YOU OPEN YOUR GLIDER CARTON PLEASE ENSURE YOU HAVE ALL THE ITEMS:

No.	FIGURE	SPECIFICATON	QUANTITY
6.		M8X43mm	2
5.		1/4"X1-5/8"	4
7.		M4	1
8.		M6	1

- 1. GLIDER FRAME
- 2. OTTOMAN
- 3. CUSHION
- 4. 2X ARMREST
- 5. 4X ARMREST SCREWS
- 6. 2X BACKREST SCREWS
- 7. ARMREST ALLEN KEY
- 8. BACKREST ALLEN KEY

ASSEMBLY INSTRUCTIONS



ASSEMBLE THE FRAME & ARMRESTS

Pull the frame (1). into the position pictured. The backrest should be upwards and the base should be in the downwards position.



Unzip the armrests located on each side of the frame (1). There are 2 holes located at the top of each armrest. Place 2 (5) Armrest screw and the armrest (4). Repeat on both sides. Once tightened close the zipper.

ASSEMBLY INSTRUCTIONS

ASSEMBLE THE FRAME

Pull the frame (1). into the position pictured. The backrest should be upwards and the base should be in the downwards position.



Place the cushion (3) over the backrest and the bottom seat. They should be placed over the bars as shown.

Place one (6) backrest screw on the back of the glider chair and tighten it with the (8) backrest allen key. This located on the back of the frame

On the base of the cushion (3) there are some elastic tighteners which attach to the base of the glider chair. Place them around protrusion on the base.

HOW TO USE

HOW TO USE THE HANDLE:



To lock the backrest of the glider chair
pull the lever upwards



To have the glider as free flowing
pull the lever downwards



WARRANTY AGAINST DEFECTS.

All Love n care products are guaranteed for twelve months from the date of purchase.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This covers against faults which develop through faulty materials and workmanship. Misuse, accidental damages, normal wear and tear or neglect are not covered.

If a fault becomes apparent, please return the item to the store of purchase with your receipt. You must inform the store what the defect is. We will then arrange for its repair or it will be assessed for replacement as expediently as possible. The benefits of this warranty are in addition to other right and remedies under the law in relation to the goods or services to which this warranty relates.

If you are unable to return the item to the store of purchase, you can contact Love N Care on free call 1300 732 599. We will then organise for either somebody to inspect the item or arrange for a courier to pick it up and return it back to you.

For more information, please contact us:



Love N Care Pty Ltd.

Email: info@lovencare.com.au

Web: www.lovencare.com.au

Ph: 1300 732 599 Fax: 02 9774 4633



Please fill in this section to validate your warranty and send to: 297 Canterbury Rd Revesby NSW 2212.

Name: _____

Store Purchased: _____

Address: _____

Date Purchased: _____

Product Name/No: _____



Contact Us

Head Office:

Love N Care Pty Ltd.
297-299 Canterbury Rd, Revesby
NSW 2212 Australia
Contact No: 02 9774 4655
Fax: 02 9774 4633
Email: info@lovencare.com.au
Website: www.lovencare.com.au

Brisbane
7-9 Eileen Street
Underwood QLD 4119 Australia
Contact No: 07 3290 4217
Fax: 07 3209 5019

Western Australia
5 Modal Crescent
Canning Vale WA 6155 Australia
Contact No: 08 9455 4972
Fax: 08 9455 4728

let's be friends!

 <http://www.facebook.com/lovencare1>

 http://twitter.com/love_ncare



100 % AUSTRALIAN OWNED SINCE 1984

lovehncare™
lovencare.com.au