

1. Before feeding, wash your hands and apply liners to protect against diaper leaks.

2. Fill up feeding bottles at intervals. Wash the feed bottle down.

3. Read the instructions on the product carefully and use the product. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE ADVERSE HEALTH EFFECTS. ALWAYS READ THE INSTRUCTIONS FOR ALL YOUR MEDICINES.

- 4. Always use the correct amount of product.
- 5. Do not use the product if it is past its expiry date.
- 6. Do not use the product if it is damaged.
- 7. Do not use the product if it is contaminated.
- 8. Do not use the product if it is expired.
- 9. Do not use the product if it is not suitable for your baby.
- 10. Do not use the product if it is not suitable for your baby.
- 11. Do not use the product if it is not suitable for your baby.
- 12. Do not use the product if it is not suitable for your baby.




**BP 6100**

**TWINSTAR**


INSTRUCTION METHOD

## 1. TO OPEN:


A. Release storage latch on side of stroller.



B. Lift handle up until locking latches on both sides of the seat can be seen and heard to engage.




C. Ensure locking latches are properly engaged before placing child in stroller.



## 2. TO ASSEMBLE FRONT WHEEL:

A. Place each front wheel assembly onto frame leg until snapped into place.




B. Push wheel assembly onto pin until it snaps in place.


C. Repeat for other wheel.

### 3. TO ASSEMBLE REAR AXLE & WHEEL:

A. Slide axle through all 3-hole openings as shown.




B. Push rear wheel onto axle until it snaps. Repeat for another side.



Pull on each wheel to be sure they are securely attached.

### 4. TO USE BRAKES:


A. Press down to lock



B. Pull up to unlock.


### 5. TO ADJUST THE SEAT BACK:

The back of the seat has 3 positions. To adjust your seat in either the upright or recline position, pull up on the metal bar at back of seat and adjust to desired position.




### 6. TO ADJUST THE FOOTREST:

Press both levers and adjust to the required position.



### 7. TO USE SAFETY BAR

The front safety bar can be fully taken off when pressing the left and right side push buttons.




### 8. HARNESS:

To correctly fit the harness first attach the lap strap clips together with the crotch strap. Fit the shoulder straps over the shoulder and clip to the central buckle.


Adjust the harness to the correct length using the adjuster.

**WARNING:** Use the harness at all times.




## 9. TO FOLD:

- A. Before folding stroller, fold canopy and apply brakes to prevent stroller from moving.



- B. Pull up folding latches at sides of handle. Fold handle down.



### WARNING

READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF PRODUCT.

FAILURE TO FOLLOW THESE WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

- Always buckle up your child with five-point safety harness provided. Together with full shoulder harness.
- We recommend use of an approved safety harness at all time securing to "D" rings fitted
- Never leave your child unattended.
- Do not use with child on stairways/escalators, unless extreme care is taken if stroller is used on stairs/escalators.
- Always use the brakes when you are parked.
- Do not lift stroller by the bumper bar.
- Do not over load the parcel carrier or bag or attach a shopping bag since the stroller.
- Do not use the stroller near an open fire or exposed flame.