

loveⁿcare™



Instructions for Uni Coupe Stroller & Toddler Seat BP 9756/BP 9762

info@lovencare.com.au
www.lovencare.com.au

loveⁿcare™

Congratulations on your new quality Love N Care product from our exclusive range of baby products. This exceptional design combines the most unique features that any baby product offers.

We are confident that you will appreciate its many highlights, including its reliability and durability. Your new product has been manufactured to comply with the Highest Quality Standards and comes with a 12-month warranty.

As you will soon learn there are many more great features about your new Love N Care product.

Maximum weight capacity of Uni Coupe Stroller & Toddler Seat combined should
not exceed 40KG
Complies with: AS 2088:2000

WARNING

A CHILDS SAFETY IS YOUR RESPONSIBILITY

Never leave a child unattended.

Children should be harnessed at all times.

Use seat belt provided to avoid serious injury from falling or sliding.

The child should be kept clear of moving parts when making any adjustments.

For safety this unit requires inspection and maintenance by the user.

Overloading, incorrect folding and the use of non-approved accessories may damage or break this unit.

Be certain the unit is fully and properly latched into position before allowing child near stroller.

Always read instructions carefully.

Single Maximum weight 25kg, Double Max weight 40kg

This unit should not be used near exposed flame.

Always apply brakes when unit is parked or loading or unloading children.

This unit is not suitable for Running, Jogging or Skating.

This product is produced in accordance with Safety Standards

EN 1888:2003

AS/NZ 2088:2000

loveⁿcare

To Open The Stroller:

- Remove pram from the box and place all accessories to one side.
- Unlock the locking clip, located on the side of the pram Fig 1
- While holding the handle bars place your foot on the back axel and lift the pram up, until you hear it click into place on both sides. Fig 2 Fig 3

Fig 1



Fig 3



Inserting the wheels:

Rear Wheels

- **Insert** the back wheels by simply pushing them into the housing on the axel until they click in. Test the wheels by trying to pull on them to see if they fall off. Repeat on second wheel. Fig 4
- To **remove** the rear wheels, simply press the quick release button in the middle of the wheel and pull out. Fig 5
- To **lock** the back wheels, simply push down in the centre of the back footrest; push up to release the brake. Fig 6

Fig 4



Fig 5



Fig 6



Front Wheels

- **Insert** the front wheels by inserting them into the front housing by pushing on the button until you hear it click into place. Test each wheel to make sure they have been inserted properly.
- To **fix** the front wheels, make sure the wheels are facing the rear, turn the button located on front footrest to lock wheels, to swivel wheels simply turn button back in reverse position.
- To **remove** the front wheels simply press the quick release button at the front and remove wheels.
- To **lock** the front wheels simply push the red lever located on the side of each wheel down; to unlock simply bring the same lever back up.

Fig 7



Fig 8



Fig 9



Fig 10



Attaching the Hood:

- Attach the hood by clipping into the housing located on the frame.
- To remove the hood push down on the black clip located on either side and pull out. (As shown in Fig 11)
- The hood can be adjusted forward or backwards to suit your desired position, there is also a window canopy for your convenience which allows you to see your baby at all times.

Attaching the Front Bumper Bar:

- Insert the bumper bar into the frame of the seat and click into place.
- To remove the bumper bar, simply push on either side the small oval shaped button and lift out. (As shown in Fig 12)



To adjust the Backrest:

- To recline the back rest squeeze both red levers while holding the material on the bottom and wither pull up or down to reach your desired position. (As shown in Fig 13)



To adjust the harness:

This stroller has been designed with a 5 – point harness for the safety of your child, your child must always be secured in this harness whilst in use. (As shown in Fig 14)

- The safety harness is adjustable, and to release the harness you should press the buckle at either side to remove it.
- To secure the harness push the buckles in, you will hear a click which means the harness has been secured.
- To adjust the harness simply thread and tighten accordingly to suit your child.



To Reverse The Handle Bar:

- Lift both levers at the same time which are located on the arm frame of the jogger upwards and then gently push the handle back. Repeat this step to return the handle back to stroller view. (As shown in Fig15)



To Close the Stroller:

- Pull the levers on each side of the frame up and slowly bring down until it stops, then push the red secondary safety located on the front of the pram before continuing to completely close the pram. The pram should then automatically lock. (As shown in Fig 16)



Uni Coupe Toddler Seat Assembly Instructions:

WARNING:

- Never leave your child unattended in the toddler seat.
- Always use the harness provided to secure your child while in the seat.
- Always assist your child in and out of the toddler seat.
- Do not use the seat with a child under the age of 10 months old.
- Excessive leaning to one side may cause the jogger to become unstable.
- Do not use this seat with any other brand product.
- Always secure the toddler seat to the frame correctly before use.
- Always check all parts before use for any breakages or damages. If any parts are found to be damaged discontinue use immediately.

Failure to follow the correct assembly instructions may render your warranty and could cause serious injury to your child and also damage the jogger.

Assembly Instructions:

- 1) Remove the front bumper on the jogger and put a side.
- 2) Remove the toddler seat from the box and unfold.
- 3) Unfasten fabric on stroller arms by unclipping the pres studs on side of arms. Fold back under-flaps and re fasten fabric to arm rest. (As shown in Fig 1)
- 4) Slide the toddler seat into the front bumper bar slots. (As shown in Fig 2)
- 5) Clip the seat in place, by pushing down firmly on both sides, making sure the latches are clipped correctly and securely. (As shown in Fig 3)
- 6) To remove the Toddler Seat simply Follow the above instructions in reverse.

Fig 1



Fig 2



Fig 3



loveⁿcare™

Another reliable product from Love N Care
Excellence ♥ Intelligence ♥ Caring

Contact Us:

1300 732 599